

INSTRUCTIONS

MODEL AVP-AV-HV3-PS-DP PULSE GENERATOR

S.N.:

WARRANTY

Avtech Electrosystems Ltd. warrants products of its manufacture to be free from defects in material and workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace said defective item. This warranty does not apply to units which have been disassembled, modified or subjected to conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.

TECHNICAL SUPPORT

Phone: 613-226-5772 or 1-800-265-6681

Fax: 613-226-2802 or 1-800-561-1970

E-mail: info@avtechpulse.com

World Wide Web: <http://www.avtechpulse.com>

TABLE OF CONTENTS

WARRANTY.....	2
TABLE OF CONTENTS.....	4
FIG. 1: PULSE GENERATOR TEST ARRANGEMENT.....	5
GENERAL OPERATING INSTRUCTIONS.....	6
Fig. 2 FRONT PANEL CONTROLS.....	8
FRONT PANEL CONTROLS.....	9
Fig. 3 BACK PANEL CONTROLS.....	10
Fig. 4 SYSTEM BLOCK DIAGRAM.....	12
SYSTEM DESCRIPTION AND REPAIR PROCEDURE.....	13
PERFORMANCE CHECKLIST.....	14

FIG. 1: PULSE GENERATOR TEST ARRANGEMENT

GENERAL OPERATING INSTRUCTIONS

- 1) The bandwidth capability of components and instruments used to display the pulse generator output signal (attenuators, cables, connectors, etc.) should exceed ten gigahertz.
- 2) The use of 40 dB attenuator at the sampling scope vertical input channel will insure a peak input signal to the sampling scope of less than one Volt.
- 3) The output pulse widths are controlled by means of the front panel one turn PW controls. The controls should initially be set maximum clockwise and the pulse width adjusted using an oscilloscope.
- 4) The output pulse amplitudes are controlled by means of the front panel one turn AMP control. The pulse width may change by several nanoseconds as the output amplitude is reduced from maximum to minimum. Therefore it is convenient to first set the desired amplitude and then set the desired pulse width. Rotation of the PW pot causes the position of the falling edge of the pulse to change.
- 5) Some properties of the output pulse may change as a function of the amplitude pot setting. For some demanding applications, it may be desirable to use a combination of external attenuators and the amplitude pot to achieve the desired output amplitude.
- 6) The relative delay between the A and B pulse may be varied from -5 to $+5$ ns using the one turn delay B control. Pulse A or Pulse B may be turned on or off using the corresponding front panel On-Off switches.
- 7) To DC offset the output pulse connect a DC power supply set to required DC offset value to the back panel terminals marked O.S. The maximum attainable DC offset voltage is ± 50 Volts. (option).
- 8) To voltage control the output pulse width, set the rear panel switch in the EXT position and apply 0 to $+10$ V to connector A ($R_{IN} \geq 10K$). (EW option),
- 9) To voltage control the output amplitude, set the rear panel switch in the EXT position and apply 0 to $+10$ V to connector A ($R_{IN} \geq 10K$). (EA option).
- 10) The unit can be converted from 120 to 240V 50-60 Hz operation by adjusting the voltage selector card in the rear panel fused voltage selector-cable connector assembly.

11) For additional assistance:

Tel: (613) 226-5772

Fax: (613) 226-2802

Fig. 2 FRONT PANEL CONTROLS

FRONT PANEL CONTROLS

- (1) ON-OFF Switch. Applies basic prime power to all stages.
- (2) TRIG In. The AVP unit requires a 50 ns (or wider) TTL level pulse applied at the TRIG input in order to trigger the output stages. In addition in this mode, the scope time base must be triggered by the external trigger source.
- (3) PW Control. A one turn control which varies the output pulse width from 0 to 2 ns.
- (4) AMP Control. A one turn control which varies the output pulse amplitude from 0 to 14V to a fifty ohm load.
- (5) OUT. SMA connector provides output to 50 ohms.
- (6) DELAY-B. One turn control varies the delay of Pulse B relative to A from -5 to +5 ns.
- (7) On-Off. Two position switches to turn Pulse A (or B) On (or Off).

Fig. 3 BACK PANEL CONTROLS

- (1) FUSED CONNECTOR, VOLTAGE SELECTOR. The detachable power cord is connected at this point. In addition, the removable cord is adjusted to select the

desired input operating voltage. The unit also contains the main power fuse (0.5A SB).

- (2) AMP A, AMP B. To voltage control the output amplitude, set the switch in the EXT position and apply 0 to +10 volts to the A BNC connector ($R_{IN} > 10K$) (option).
- (3) PWA, PWB. To voltage control the output pulse width, set the switch in the EXT position and apply 0 to +10 Volts to the A BNC connector ($R_{IN} > 10K$) (option).
- (4) OS. To DC offset the output, apply the required DC potential (0 to ± 50 VDC) to the "OS" solder terminals ($\pm 100mA$ max).

Fig. 4 SYSTEM BLOCK DIAGRAM

SYSTEM DESCRIPTION AND REPAIR PROCEDURE

The AVP-AV-HV3-C consists of a pulse generator module (AVP-AV-HV3-PG), a clock module (AVP-AV-HV3-CL) and a power supply board which supplies +15 Volts (600 mA max) to the pulse generator module. In the event that the unit malfunctions, remove the instrument by removing the four Phillips screws on the back of the unit. The top cover may be slid off. Measure the voltage at the +15V pin of the PG module. If this voltage is substantially less than +15 Volts, unsolder the line connecting the power supply and PG modules and connect 50 Ohm 10 W load to the PS output. The voltage across this load should be about +15 V DC. If this voltage is substantially less than 15 Volts the PS module is defective and should be repaired or replaced. If the voltage across the resistor is near 15 Volts, then the PG module should be replaced or repaired. The sealed PG Module must be returned to Avtech for repair (or replacement). The clock module provides a 0.1 us TTL level trigger pulse at pin 2 to trigger the PG module and a 0.1 us TTL level sync pulse at pin 3 to trigger the sampling scope display device. The output at pin 3 precedes the output at pin 2 by almost 0 to 100 ns depending on the DELAY control setting. The clock module is powered by +5.8 V supplied by the PG module (from pin 5 to pin 1). With the INT-EXT switch in the EXT position, the clock module is disconnected from the PG module. The clock module is functioning properly if:

- a) 0.1 us TTL level outputs are observed at pins 2 and 3.
- b) The PRF of the outputs can be varied over the range of 1kHz to 1MHz using the PRF and PRF RANGE controls.
- c) The relative delay between the pin 2 and 3 outputs can be varied by at least 500 ns by the DELAY controls.

The sealed clock module must be returned to Avtech for repair or replacement if the above conditions are not observed.

PERFORMANCE CHECKLIST