

## INSTRUCTIONS

- 1) To install the 10 turn pots it is necessary to remove the one turn pots and to then increase the hole size from  $\frac{1}{4}$ " to  $\frac{13}{32}$ ". Also, it is necessary to add the 0.074" locking hole for the knob (see enclosed Kilo instructions).
- 2) It may be necessary for you to move the D<sub>2</sub> and PW<sub>2</sub> modules to provide clearance for the D<sub>3</sub> and D<sub>4</sub> pots. We enclose an L bracket which could be used to reposition the D<sub>2</sub> and PW<sub>2</sub> modules (see enclosed sketch).
- 3) This field modification voids the Avtech warranty.