

AVO-2W-PG

INSTALLATION NOTES

- 1) The connections to the module are to be as shown in the attached sketch.

- 2) Take exceptional care not to damage the 2 RG174 cables when soldering to the chassis. Avoid the use of excessive heat.

- 3) For additional assistance:

Fax: (613) 226-2802
Tel: (613) 226-5772
e-mail : info@avtechpulse.com