

AVO-5A-PG-P

INSTALLATION NOTES

- 1) The connections to the module are to be as shown in the attached sketch.
- 2) Note that heat sink compound must be used when attaching the module to the chassis.
- 3) Take exceptional care not to damage the 4 RG174 cables when soldering to the chassis. Avoid the use of excessive heat.
- 4) For additional assistance:

Fax: (613) 226-2802

Tel: (613) 226-5772