## **MODEL AVX-S4-PSI**

## **INSTRUCTIONS**

1) Connect the pulse source, CW source and load as shown below. Note: the negative polarities are required and no output will be obtained if positive polarities are employed. Slowly increase the amplitudes (From 0) to confirm the expected output is obtained.