

## AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

BOX 5120 STN. F
 OTTAWA, ONTARIO
 CANADA K2C 3H4
 TEL: (613) 226-5772
 FAX: (613) 226-2802

## -PW-TIB

## INSTALLATION INSTRUCTIONS

- 1) Remove the top cover of the instrument and make a record of the colors of the wires connnected to the PINS 1 to 5 in the original unit. The top cover is removed by removing the four Phillips screws on the back panel and sliding the top cover back and off.
- 2) Unscrew the original module by removing the 2-56 Phillips mounting screws on the bottom surface of the instrument.
- 3) Install the 2-56 screws into the replacement module and transfer the wires (one by one) from the PINS on the original module to the replacement module. Also transfer the RG174 cable.

Walter J. Chudobiak Chief Engineer July 26, 1994

アノアロ 1224 N donal De -2 my b MA-61-1-NA-1-13-51 50 K 50-50 05 P 50 K 3 r 7806 7824 130 DEM 1/4/2 4194 1 0.334 2003 (6)40 1 × ×

July 26/94