

P.O. BOX 265 OGDENSBURG, NY U.S.A. 13669-0265 TEL: (315) 472-5270 FAX: (613) 226-2802

## AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

TEL: 1-800-265-6681 FAX: 1-800-561-1970 U.S.A. & CANADA

e-mail: info@avtechpulse.com

BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772 FAX: (613) 226-2802

## INSTRUCTIONS

## MODEL AVI-V-C-URB PULSE GENERATOR

S.N.:

### WARRANTY

Avtech Electrosystems Ltd. warrants products of its manufacture to be free from defects in material and workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace said defective item. This warranty does not apply to units which have been dissembled, modified or subjected to conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation or liability assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.





.

:

••

Notes:

- The bandwidth capability of components and instruments used to display the pulse generator output signal (attenuators, cables, connectors, etc.) should exceed five gigahertz.
- 2) The use of 50 dB attenuator at the sampling scope vertical input channel will insure a peak input signal to the sampling scope of less than one Volt.
- 3) The TRIG output channel provides TTL level signals. To avoid overdriving the TRIG input channel of some scopes, a 30 dB attenuator should be placed at the input to the scope trigger channel. The TRIG output precedes the main output when the front panel ADVANCE-DELAY switch is in the ADVANCE position. The TRIG output lags the main output when the switch is in the DELAY position.
- 4) To obtain a stable output display the PRF controls on the front panel should be set mid-range while the PRF switch may be in either range. The front panel TRIG toggle switch should be in the INT position. The front panel DELAY control and the scope triggering controls are then adjusted to obtain a stable output. The scope may then be used to set the desired PRF by rotating the PRF controls.
- 5) The output pulse width is controlled by means of the front panel one turn PW control. The control should initially be set maximum clockwise and the pulse width adjusted using an oscilloscope.
- 6) The output pulse amplitude is fixed at +50 Volts.
- 7) To DC offset the output pulse connect a DC power supply set to required DC offset value to the back panel terminals marked O.S. The maximum attainable DC offset voltage is ±50 Volts (option).
- 8) An external clock may be used to control the output PRF of the AVI unit by setting the front panel TRIG toggle switch in the EXT position and applying a 0.2 us (approx.) TTL level pulse to the TRIG BNC connector input. For operation in this mode, the scope time base must also be triggered by the external clock. The propagation delay time in the externally triggered mode is about 300 ns.

- 9) To invert the output of units with the dual output polarity option (-PN), connect the AVX-3 module to the output port of the AVI unit. An inverted pulse is then obtained at the out port of the AVX-3 module.
- 10) To invert the output of units with the dual output polarity option (-PN) and the offset option (OS), connect the AVX-3-T module to the OUT port of the AVI unit. A negative pulse with a rise time ≤ 200 ps is then obtained at the OUT port of the AVX-3-T unit. To offset the negative pulse, apply the required DC level to the DC terminal of the AVX-3-T unit.
- 11) <u>MONITOR OUT M</u>. Provides an attenuated (x10) coincident replica of the main positive output pulse to fifty Ohms. (option).
- 12) The unit can be converted from 110 to 220V 50-60 Hz operation by adjusting the voltage selector card in the rear panel fused voltage selector-cable connector assembly.
- 13) For additional assistance:

Tel:	(613)	226-5772
Fax:	(613)	226-2802



Fig. 2

## FRONT PANEL CONTROLS

- (1) <u>ON-OFF Switch</u>. Applies basic prime power to all stages.
- (2) <u>PRF Control</u>. Varies PRF from 10 Hz to 5 kHz as follows:

Range	1	20	Hz	to	200	Hz
Range	2	200	Hz	to	2.0	kHz
Range	3	2.0	kHz	to	20	kHz

- (3) <u>DELAY Control</u>. Controls the relative delay between the reference output pulse provided at the TRIG output (4) and the main output (5). This delay is variable over the range of 0 to about 0.5 us (RANGE 1) and 0.5 to 5.0 us (RANGE 2). The TRIG output precedes the main output when the ADVANCE-DELAY switch is in the ADVANCE position and lags when the switch is in the DELAY position.
- (4) <u>TRIG Output</u>. This output is used to trigger the scope time base. The output is a TTL level 100 ns (approx.) pulse capable of driving a fifty Ohm load.
- (5) <u>OUT Connector</u>. SMA connector provides output to a fifty Ohm load.
- (6) <u>PW Control</u>. A one turn control which varies the output pulse width.
- (7) <u>EXT-INT Control</u>. With this toggle switch in the INT position, the PRF of the AVI unit is controlled via an internal clock which in turn is controlled by the PRF controls. With the toggle switch in the EXT position, the AVI unit requires a 50 ns (or wider) TTL level pulse applied at the TRIG input in order to trigger the output stages. In addition, in this mode, the scope time base must be triggered by the external trigger source.





•

G.

BACK PANEL CONTROLS

. 2

- (1) <u>FUSED CONNECTOR, VOLTAGE SELECTOR</u>. The detachable power cord is connected at this point. In addition, the removable cord is adjusted to select the desired input operating voltage. The unit also contains the main power fuse (0.25 A SB).
- (2) <u>DC OFFSET Input</u>. To DC offset the output pulse, connect a DC power supply set to the desired offset value to these terminals. The maximum allowable DC offset voltage is ±50 Volts (option).
- (3) <u>MONITOR OUT M</u>. Provides an attenuated (x10) coincident replica of the main positive output pulse to fifty Ohms (option).

Fig. 4

SYSTEM BLOCK DIAGRAM



#### SYSTEM DESCRIPTION AND REPAIR PROCEDURE

The AVI-V-C consists of a pulse generator module (AVI-V-PG), a clock module AVI-V-CL and a power supply board which supplies +15 Volts (600 mA max) to the pulse generator module. In the event that the unit malfuctions, remove the instrument cover by removing the 4 Phillips screws on the back panel of the unit. The top cover may then be slid off. Measure the voltage at the +15 V pin of the PG module. If this voltage is substantially less than +15 Volts, unsolder the line connecting the power supply and PG modules and connect 50 Ohm 10 W load to the PS output. The voltage across this load should be about +15 V DC. If this voltage is substantially less than 15 Volts the PS module is defective and should be repaired or replaced. If the voltage across the resistor is near 15 Volts, then the PG module should be replaced or repaired. The sealed PG module must be returned to Avtech for repair (or replacement). The clock module provides a 0.1 us TTL level trigger pulse at pin 2 to trigger the PG module and a 0.1 us TTL level sync pulse at pin 3 to trigger the sampling scope display device. The output at pin 3 precedes the output at pin 2 by almost 0 to 100 ns depending on the DELAY control setting. The clock module is powered by +5.8 V supplied by the PG module (from pin 5 to pin 1). With the INT-EXT switch in the EXT position, the clock module is disconnected from the PG module. The clock module is functioning properly if:

- a) 0.1 us TTL level outputs are observed at pins 2 and 3.
- b) The PRF of the outputs can be varied over the range of 0.05 kHz to 5 kHz using the PRF and PRF RANGE controls.
- c) The relative delay between the pin 2 and 3 outputs can be varied by at least 100 ns by the DELAY control.

The sealed clock module must be returned to Avtech for repair or replacement if the above conditions are not observed.

	ALC: NOT		NI N7 20		
1.	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				··· .
					1.
Lab				£ 1.	V <sub>I-1+</sub>
0.4324		j#Letal	10.0388		Le L-

## AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

<u>_</u>	P.O. BOX 26 OGDENSBURG, N U.S.A. 13669-02 TEL: (315) 472-52 FAX: (613) 226-29	5 TEL: 1-800 IY FAX: 1-800 55 U.S.A. & 70	0-265-6681 0-561-1970 CANADA	✗ BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772		
	Fax Ref No:	1118	From: Avtech	Electrosystems Ltd.		
	To:	University of Rochester	• Our Fax No:	(613) 226-2802		
	-	Lab for Laser Energetic	S Date:	January 8, 1997		
	Attn:	William Byrne Tel: 716-275-7463	Receivers Fax No:	716-275-0135		
	Subject:		No. of pages:	1		

Re: Your P.O. #9718763, Release #001

I am pleased to acknowledge your Purchase Order as follows:

one Model AVI-V-C-P-URB

Note that this price includes our standard 5% academic discount

\$2,145.00 US each, FOB destination

-URB suffix denotes output amplitude fixed at +50 Volts and unit selected to provide rise time as low as possible (hopefully 250 ps).

Delivery: March 7/97

Regards

61

Dr. Walter Chudobiak Chief Engineer

WC:pr



## AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

11	P.O. BOX 26 OGDENSBURG, 1 U.S.A. 13669-02 TEL: (315) 472-52 FAX: (613) 226-28	5 TEL: 1-800-265- NY FAX: 1-800-561- 165 U.S.A. & CANA 170 02 e-mail: info@avtechp	6681 1970 .DA pulse.com	BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772 FAX: (613) 226-2802
	Fax Ref No:	1084	From: Avtech	Electrosystems Ltd.
	To:	University of Rochester Lab for Laser Energetics	Our Fax No:	(613) 226-2802
		250 East River Road Rochester, NY 14623	Date:	December 16, 1996
	Attn:	Mark Skeldon Tel: 716-275-4781	Receivers Fax No:	716-275-5960
	Subject:	AVI series waveforms	No. of pages:	2

- As per our series of telephone conversations, I enclose a test waveform for our Model AVI-V-C (see pages 22 and 23, Cat. No. 9). If we attempt to reduce the rise time (as per the -TR option or as per -HV1) we introduce the front porch aberration. The amplitude cannot be increased above 50 Volts. (copy of waveform mailed).
- 2) We might be able to get the rise time down to less than 250 ps by omitting the amplitude control function (i.e. output fixed at +50 Volts) and by picking and choosing.

Regards

/Dr. Walter Chudobiak Chief Engineer

WC:pr



AVI-V-C-P

BOWARE !! V.G. 16

# Feb. 19/97

-OS -PN -M Disk: AVI AVIVCURB.INS