



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS
SINCE 1975

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

TEL: 1-800-265-6681
FAX: 1-800-561-1970

e-mail: info@avtechpulse.com
<http://www.avtechpulse.com>

P.O. BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

Visio drawing
INS *correct*
mf 01.22.02

MODEL AVB2-TC-SB2 MONOCYCLE GENERATOR

S.N.:

WARRANTY

Avtech Electrosystems Ltd. warrants products of its manufacture to be free from defects in material and workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace said defective item. This warranty does not apply to units which have been disassembled, modified or subjected to conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.

TECHNICAL SUPPORT

Phone: 613-226-5772 or 1-800-265-6681
Fax: 613-226-2802 or 1-800-561-1970

E-mail: info@avtechpulse.com
World Wide Web: <http://www.avtechpulse.com>

TABLE OF CONTENTS

WARRANTY 2

TABLE OF CONTENTS 3



FIG. 1: MONOCYCLE GENERATOR TEST ARRANGEMENT..... 4

GENERAL OPERATING INSTRUCTIONS 5

PERFORMANCE CHECK SHEET 7


Manual Reference: Q:\office\instructword\Avb\AVB2-TC-SB2eda.doc, created January 10, 2000

FIG. 1: MONOCYCLE GENERATOR TEST ARRANGEMENT



GENERAL OPERATING INSTRUCTIONS

- 1) The bandwidth capability of components and instruments used to display the pulse generator output signal (attenuators, cables, connectors, etc.) should exceed one gigahertz.
- 2) The use of 60 dB attenuator will insure a peak input signal to the sampling scope of less than one volt.
- 3) The chassis should be securely bolted to a heat sink capable of dissipating about 10 Watts.
- 4) In general, the pulse generator trigger delay control should be set in the < 100 ns range. Other settings should be as shown in the above diagram. The monocycle generator output is delayed with respect to the trigger input signal by about 50 ns (typically).
- 5) The frequency control cable (see attached graph) may be fabricated from RG174 miniature coax or from 85 mil semi-rigid cable. Increasing the cable length increases the "T" of the output waveform as follows:



- 6) PWP and PWN are controlled by varying the DC potential on pins PWP and PWN from 0 to +5 Volts using either a 1K pot or an equipment switched resistor arrangement. PWP and PWN can be varied separately by removing the connecting shorting bar and employing two pots (or switches).
- 7) Two 4 cable groups of RG174 50 Ohm cables protrude for about 5 feet from the side of the chassis. These open circuited cables may be coiled as required but note that potentials as high as 330 VDC are present on the center conductor.

- 8) **CAUTION:** The +15 Volts supply should be disconnected when changing or removing the frequency control cable. (DC potential as high as 380V are applied to the center conductor).
- 9) A 250 Ohm pot may be used as shown in Fig. 1 to provide amplitude control
- 10) For additional information:

Tel: (613) 226-5772

Fax: (613) 226-2802

Email: info@avtechpulse.com

8854



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS
SINCE 1975

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

TEL: 1-800-265-6681
FAX: 1-800-561-1970

e-mail: info@avtechpulse.com
<http://www.avtechpulse.com>

P.O. BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

August 12, 1998

Brian Starkoski
Sunnybrook Health Sciences Centre
2075 Bayview Avenue
North York, Ontario
M4N 3M5

Dear Brian:


Following our telephone conversation of August 11th, I am pleased to provide a price and delivery quotation for a special purpose monocycle generator meeting the following specifications:

| | |
|------------------------------|--|
| Quote No: | 8854 |
| Model designation: | AVB2-TC-SB1 This module unit employs the same technology as Model AVB2-C, S.N. 4200 |
| Frequency: | 100 to 170 MHz (Controlled by a delay line which connects to two SMA connectors on the 1.7" x 3.0" face). |
| Amplitude: | 0 to 300 Volts peak to peak. AMP control is via a user-supplied 250 Ohm pot in the output line. Instructions included. |
| PRF: | 0 to 20 kHz |
| Input trigger required: | TTL, PW \geq 50 ns |
| Prime power: | + 15 VDC, 400 mA |
| Chassis size: | 1.7" x 3.0" x 6.0" |
| Input and output connectors: | SMA (on 1.7" x 3.0" face) |

Other: See standard AVB2-TC-C, page 85, Cat. No. 10.
Price: \$3,598.00 US each, FOB destination.
Note: This price includes our standard 5% academic discount.
GST: 7% extra.
PST: 8% extra, if applicable.
Delivery: 60-90 days ARO.

Thank you for your continuing interest in our products. Please call me again (1-800-265-6681) if you require any additional information.

Yours truly,

A handwritten signature in black ink, appearing to read 'Walter Chudobiak', written in a cursive style.

Dr. Walter Chudobiak
Chief Engineer

WC:hw



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS
SINCE 1975

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

TEL: 1-800-265-6681
FAX: 1-800-561-1970

e-mail: info@avtechpulse.com
<http://www.avtechpulse.com>

P.O. BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

| | | | |
|----------|--|-------------------|---------------------------|
| Fax No: | <u>4550</u> | Sender's Fax: | <u>613-226-2802</u> |
| File: | <u>Q:\office\QUOTES\Q9598.doc</u> | Receiver's Fax: | <u>416-480-5714</u> |
| To: | <u>Sunnybrook Health Sciences Centre</u> <u>North York, Ontario</u> | Receiver's Phone: | <u>416-480-6100</u> |
| Attn: | <u>Kasia Harasiewicz</u> | Date: | <u>November 2, 1999</u> |
| Subject: | <u>Price and delivery quotation</u> | Number of pages: | <u>2, including cover</u> |

Following our telephone conversation of November 2, 1999, I am pleased to provide a price and delivery quotation for a special purpose monocyycle generator meeting the following specifications:

| | |
|------------------------------|--|
| Quote Number: | 9598 |
| Model designation: | AVB2-TC-SB2 This module unit employs the same technology as Model AVB2-C, S.N. 4200 |
| Frequency: | 30 to 60 MHz (Controlled by a delay line which connects to two SMA connectors on the 1.7" x 3.0" face) and by a one turn pot which connects to three front panel solder terminals. |
| Amplitude: | 0 to 300 volts peak to peak. AMP control is via a user-supplied 250 Ohm pot in the output line. Instructions included. |
| PRF: | 1 to 10 kHz |
| Input Trigger Required: | TTL, PW \geq 50 ns |
| Prime Power: | +15 VDC, 400 mA |
| Chassis Size: | 1.7" x 3.0" x 6.0" |
| Input and Output Connectors: | SMA (on 1.7" x 3.0" face) |
| Other: | See standard AVB2-TC-C, page 85, Cat. No. 10 |
| Price: | \$3,698.00 US each, FOB destination. |
| Note: | This price includes our standard 5% academic discount. |

GST: 7% extra
PST: 8% extra, if applicable
Delivery: 45-60 days, after receipt of order.

Thank you for your continuing interest in our products. Please call me again (1-800-265-6681) if you require any further information.

Regards,

A handwritten signature in black ink, appearing to read 'W. Chudobiak', written in a cursive style.

Dr. Walter Chudobiak
Chief Engineer

WC:mf

January 10/2000
(edition A)