

P.O. BOX 265
 OGDENSBURG, NY
 U.S.A. 13669-0265
 TEL: (315) 472-5270
 FAX: (613) 226-2802

AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

TEL: 1-800-265-6681 FAX: 1-800-561-1970 U.S.A. & CANADA

e-mail: info@avtechpulse.com

BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772 FAX: (613) 226-2802

INSTRUCTIONS

MODEL AVO-9AB-C PULSE GENERATOR

S.N.:

WARRANTY

Avtech Electrosystems Ltd. warrants products of its manufacture to be free from defects in material and workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace said defective item. This warranty does not apply to units which have been dissembled, modified or subjected to conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation or liability assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.

PULSE GENERATOR TEST ARRANGEMENT

(AVX-S1 MODULE REMOVED)



Fig. l

Notes:

- The bandwidth capability of components and instruments used to display the pulse generator output signal (attenuators, cables, connectors, etc.) should exceed ten gigahertz.
- 2) The use of 40 dB attenuator at the sampling scope vertical input channel will insure a peak input signal to the sampling scope of less than one Volt.
- 3) The AVO-9AB-C contains two independent pulse generators which cover the output PW range of 0.2 to 5.0 ns (A) and 5.0 ns to 100 ns (B). A and B share a common internal clock and PW and AMP controls.
- 4) The TRIG output channel provides TTL level signals. To avoid overdriving the TRIG input channel of some sampling scopes, a 30 dB attenuator should be placed at the input to the sampling scope trigger channel.
- 5) To obtain a stable output display the PRF control on the front panel should be set mid-range while the PRF range switch may be in either range. The front panel TRIG toggle switch should be in the INT position. The front panel DELAY controls and the scope triggering controls are then adjusted to obtain a stable output. The scope may then be used to set the desired PRF by rotating the PRF control and by means of the PRF range switch.
- 6) The output pulse width is controlled by means of the front panel one turn PW control. The control should initially be set maximum clockwise and the pulse width adjusted using an oscilloscope.
- 7) The output pulse amplitude is controlled by means of the front panel one turn AMP control. The pulse width may change by several nanoseconds as the output amplitude is reduced from maximum to minimum. Therefore it is convenient to first set the desired amplitude and then set the desired pulse width. Rotation of the PW pot causes the position of the falling edge of the pulse to change.
- 8) Some properties of the output pulse may change as a function of the amplitude pot setting. For some demanding applications, it may be desirable to use a combination of external attenuators and the amplitude pot to achieve the desired output amplitude.

- 9) An external clock may be used to control the output PRF of the AVPP unit by setting the front panel TRIG toggle switch in the EXT position and applying a 0.2 us (approx) TTL level pulse to the TRIG BNC connector input.
- 10) The AVO-9AB-C unit can be converted from 120 to 240V 50-60 Hz operation by adjusting the voltage selector card in the rear panel fused voltage selector-cable connector assembly.
- 11) For additional assistance:

Tel:	(613)	226-5772
Fax:	(613)	226-2802

PULSE GENERATOR TEST ARRANGEMENT

Fig. 2

(AVX-S1 MODULE CONNECTED)



GENERAL INSTRUCTIONS

- (1) The AVX-S1 module should be connected to the AVO-9AB-C mainframe via the supplied 24" RG174 cable.
- (2) Gently insert the H1 package into the 8 pin socket assembly.
- (3) Connect the MI port to a scope via a 20 dB attenuator (50 Ohms).
- (4) The PINS on the D connector (AMP No. 57-60140) correspond to the PINS on the H1 package with the exception that PINS 4 (cathode) and 5 (anode) are not connected.
- (5) A forward DC bias may be applied to the laser diode by connecting a DC potential of 0 to -5 Volts to the DC solder terminal. The application of a small forward bias often yields a more ideal diode current waveform (as observed on the MI port). Note that the DC port must be shorted to ground if a bias is not applied.
- (6) The diode pulse current (Amps) and the Voltage at M₁ (Volts) are related as follows:

 $I_D = 0.2 V_{MI}$

AUX-SI (SN !



EUNCTIONA EQUIN. CC7



ACK Me

LASER DIODE BIAS

PRODUC



VIECH

The AVX-S series of bias insertion units is designed for applying pulse or RF CW signals and DC bias to laser diodes which insert into a high quality socket included on the mount. The bias insertion module includes the necessary networks to match the laser diode to the pulse or RF source as well as networks for applying DC bias to the diode. Optional outputs allow for monitoring of the laser diode current, voltage and a photo detector diode output. Readily available socket configurations (TO-18, TO-5, TO-3, OP-3) are shown on the following page. Note that the laser diodes are not supplied with the AVX-S series.

The AVX-S series includes 3 basic models namely the AVX-S1, AVX-S2 and the AVX-S3. The basic functional equivalent circuit for the three models are shown below. Model AVX-S1 is specifically designed for ultra high-speed, low current applications (rise times as low as 200 psec, bandwidths to 1 GHz, I < 1.0 ampere). Model AVX-S1 is employed in the AVO-9-C series of diode drivers. Model AVX-S2 is intended for application with rise times greater than 2 nsec and currents above 1 ampere. Model AVX-S3 is specifically designed for use with the AVO-2 and AVO-5 series pulse generators (which provide currents in the range of 5 to 50 amperes).

The input series blocking capacitor in Models AVX-S1 and AVX-S2 presents a low impedance to RF CW signals and to baseband pulses while the shunt indicator presents a high impedance to RF (or pulse) signals but an extremely low impedance to the DC bias. The resistor in series with the laser diode is selected to insure that the impedance at the IN port is 50 ohms. Normally a laser diode resistance of 3 ohms is assumed.

The optional diode current monitor (M_{I}) provides an output waveform (to 50 ohms) which is an attenuated replica of the laser diode current. The output amplitude (V_{MI} , volts) and diode current (I_D , Amps) are related as follows:

S1:
$$I_D = 0.2V_{MI}$$
 -S2: $I_D = V_{MI}$

The optional diode voltage monitor (MV) provides an output waveform that may be related to the voltage across the laser diode (V_D , volts) as follows:

S1:
$$V_D = 10 (V_{MV} - V_{MI}) - S2: V_D = 10 V_{MV}$$



- Socket mounting of laser diodes
- Peak currents from 100 mA to 48 Amps
- Pulse widths from 0.4 to 200 nsec
- Rise times from 0.2 to 2.0 nsec
- Pulse or CW RF
- Diode current and voltage monitor options

Model AVX-S3 is available in four different versions (AVX-S3A, AVX-S3B, AVX-S3C and AVX-S3D) all of which include a matching transformer which effectively boosts the laser diode current beyond that provided by the pulse source.

Model AVX-S3A is designed to match 50 ohm pulse generators such as Model AVQ-2-C to 12 ohm loads with peak currents of 5 amperes. Consequently, the resistor R_S in the equivalent circuit for this model is 10 ohm. This resistor is accessible in all AVX-S3 models and may be changed by the user (by desoldering). The series resistance of the laser diode and the resistor R_S must equal the pulse generator source impedance divided by N². Consequently, if the series resistance of the laser diode is relatively high, it then may be necessary to reduce the value of R_S. Model AVX-S3B is designed to match 50 ohm pulse generators such as Model AVO-5-C to 3 ohms and will provide peak diode currents up to 28 amperes. Model AVX-S3C is designed to match Models AVO-2W-C and AVO-2-C (25 ohm source impedance) to load resistance of about 5 ohms and will provide peak diode currents as high as 10 amperes. Model AVX-S3D is designed for use with Model AVO-5B-C and will provide up to 48 amperes of diode current.

Two optional SMA output connectors provide attenuated coincident replicas of the diode current (-MI option) and diode voltage (-MV option) as per the following relationships (Amps, Volts):

$$I_D = -\frac{10 V_{MI}}{R_S}$$
 $V_D = 10 (V_{MV} - V_{MI})$

All AVX-S3 units include two foot long input cables with SMA male connectors.

When ordering members of the AVX-S family, the customer must specify the basic model number (eg. AVX-S1) and the following additional information.

- a) Diode package type (eg. TO-18) and the required pin connections (eg. anode, cathode, ground etc). See the following page for readily available package mounting. Contact Avtech for special or different packages.
- b) Desired options (eg. -MI, -MV, -MD).

Contact Avtech for your special requirements.



Model:	AVX-S1	AVX-S2	AVX-S3A	AVX-S3B	AVX-S3C	AVX-S3D
Peak diode current:	400 mA	2 Amps	5 Amps	28 Amps	10 Amps	48 Amps
Max. input amplitude:	20 volts	100 volts	150 voits	350 volts	150 volts	150 volts
Pulse width (nsec):	0.4 - 200	1 - 1000	2 - 100	2 - 100	2 - 100	5 - 500
Rise time (nsec):	0.2	0.5	0.5	1.0	0.5	2.0
Pulse PRF range:	DC - 0.5 GHz	DC - 100 MHz	DC - 10 MHz	DC-10 MHz	DC - 10 MHz	DC - 1 MHz
CW frequency range:	10 MHz - 1.0 GHz	1 - 200 MHz	•	•	-	•
Max. bias current:	100 mA	100 mA	100 mA	100 mA	100 mA	100 mA
Max. bias voltage:	50 volts	50 volts	50 volts	50 volts	50 voits	50 volts
Input impedance:	50 ohms	50 ohms	50 ohms	50 ohms	25 ohms	12 ohms
N:	•		2	4	2	4
Rs (ohms):	•	•	10	3	5	0.7
IN connector:	SMA					
Monitor connector:			SM	AA		
Bias connector:			Solde	er pin		
Size (in):	1.6 x 2.6 x 3.0					
Material:	Cast aluminum, blue enamel					
Mounting:	Any					



AVX-S1 FUNCTIONAL EQUIVALENT CIRCUIT





φ2.54



-

 $\overline{\Pi}$

Ι,

U

 $\phi_{0.45}$

I

ł



OP-3



1.187±.01* 30.20±0.25mm

156±.005" 3.96±0.13mm DIA 2 HOLES

LASER DIODE PHOTO DIODE DETECTOR SOCKET ASSEMBLY

MD

MI (50 OHMS)

TYPICAL PACKAGES

AVX-S2 FUNCTIONAL EQUIVALENT CIRCUIT

4

Ş

1 OHM

DC

ς

Ŵ

(50 OHMS)

47 OHMS

500 OHMS

IN PULSE OR RF



AVX-S3 INPUT ASSEMBLY (FOR OP-3 PACKAGE)

80° TYP

Bottom View



FRONT PANEL CONTROLS

Fig. 3

- (1) <u>ON-OFF Switch</u>. Applies basic prime power to all stages.
- (2) <u>PRF Control</u>. The PRF RANGE and PRF controls determine output PRF as follows:

PRF MIN PRF MAX Range 1 1000 Hz 100 Hz Range 2 1000 Hz 10 kHz Range 3 100 kHz 10 kHz Range 4 100 kHz 1 MHz

- (3) <u>DELAY Controls</u>. Controls the relative delay between the reference output pulse provided at the TRIG output (4) and the main output (7). This delay is variable over the range of 0 to at least 500 ns.
- (4) <u>TRIG Output</u>. This output precedes the main output (7) and is used to trigger the sampling scope time base. The output is a TTL level 100 ns (approx) pulse capable of driving a fifty Ohm load. The external trigger signal is applied at this input when the EXT-INT toggle switch is in the EXT position.
- (5) <u>PW Control</u>. A one turn control and two-position range switch which varies the output pulse width as follows:

Range A: 0.2 ns to 5 ns Range B: 5 ns to 100 ns

- (6) <u>AMP Control</u>. A one turn control which varies the output pulse amplitude.
- (7) OUT. SMA connector provides output to 50 Ohm load.
- (8) <u>INT-EXT-MAN Control</u>. With this toggle switch in the INT position, the PRF of the AVO-9AB-C unit is controlled via an internal clock which in turn is controlled by the PRF controls. With the toggle switch in the EXT position, the AVO unit requires a 50 ns (or wider) TTL level pulse applied at the TRIG input in order to trigger the output stages. In addition, in this mode, the scope time base must be triggered by the external trigger source. For a single pulse out, set the switch in the MAN position and push the single pulse button (9).
- (9) <u>SINGLE PULSE</u>. For manual single pulse operation, set the INT-EXT-MAN switch (8) in the MAN position and push the single pulse button.

BACK PANEL CONTROLS



Fig. 4

(1) <u>FUSED CONNECTOR, VOLTAGE SELECTOR</u>. The detachable power cord is connected at this point. In addition, the removable cord is adjusted to select the desired input operating voltage. The unit also contains the main power fuse (0.5 A SB).

Fig. 5





SYSTEM DESCRIPTION AND REPAIR PROCEDURE

The AVO-9AB-C consists of two pulse generator modules (PGA and PGB), a clock module (AVO-CL) and a power supply board which supplies +24 Volts (600 mA max) to the pulse generator module. In the event that the unit malfunctions, remove the instrument cover by removing the four Phillips screws on the back panel of the unit. The top cover may then be slid Measure the voltage at the +24 V pin of the PG module. off. If this voltage is substantially less than +24 Volts, unsolder the line connecting the power supply and PG modules and connect 100 Ohm 10 W load to the PS output. The voltage across this load should be about +24 V DC. If this voltage is substantially less than 24 Volts the PS module is defective and should be repaired or replaced. If the voltage across the resistor is near 24 Volts, then the PG module should be replaced or repaired. The sealed PG module must be returned to Avtech for repair (or replacement). The clock module provides a 0.1 us TTL level trigger pulse at Pin 2 to trigger the PG module and a 0.1 us TTL level sync pulse at Pin 3 to trigger the sampling scope display The output at Pin 3 precedes the output at Pin 2 by device. almost 0 to 100 ns depending on the DELAY control setting. The clock module is powered by +5.8 V supplied by the PG module (from Pin 2 to Pin 1). With the INT-EXT switch in the EXT position, the clock module is disconnected from the PG module. The clock module is functioning properly if:

- a) 0.1 us TTL level outputs are observed at Pins 2 and 3.
- b) The PRF of the outputs can be varied over the range of 10 Hz to 0.1 MHz using the PRF and PRF RANGE controls.
- c) The relative delay between the Pin 2 and 3 outputs can be varied by at least 500 ns by the DELAY control.

The sealed clock module must be returned to Avtech for repair or replacement if the above conditions are not observed.



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

P.O. BOX 265
 OGDENSBURG, NY
 U.S.A. 13669-0265
 TEL: (315) 472-5270
 FAX: (613) 226-2802

TEL: 1-800-265-6681 FAX: 1-800-561-1970 U.S.A. & CANADA BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772 FAX: (613) 226-2802

e-mail: info@avtechpulse.com

December 9, 1996.

Matthias Wut	tig
Lucent Techno	ologies
Room 31-303	-
700 Mountain	Avenue
Murray Hill,	NJ 07974

Tel: 908-582-6200 Fax: 908-582-4702

Dear Matthias:

Following our telephone conversation of December 9th, I am pleased to enclose the following literature:

- 1) General Catalog No. 9
- 2) Short Form Catalog No. 95
- 3) Price list

Please note that our complete catalog may be viewed on the World Wide Web at http://www.avtechpulse.com.

Models AVO-9A-C and AVO-9B-C (see pages 62 and 63) can be combined in a single chassis to provide a special purpose laser diode driver meeting the following specifications:

Model designation:	AVO-9AB-C-LT1.
Pulse width:	0.4 ns to 100 ns as follows:
	Range A: 0.4 ns to 5.0 ns Range B: 5.0 ns to 100 ns.
	Range selection is via a front panel two-position switch.
Amplitude:	0 to 200 mA.
Rise, fall time:	≤ 200 ps.

.../2

Pulse repetition frequency: Internal clock: 100 Hz to 1 MHz External trigger: 0 to 1 MHz. Single pulse: Manual push button provided. Chassis size: 3.9" x 8.5" x 14.8". Avtech style G1, see page 113). Diode mounting: Includes standard AVX-S1 style output module (see pages 80 and 81). When placing order, we will

Other:

Price:

Delivery:

45-60 days ARO.

pages 62 and 63.

package to be used.

Thank you for your interest in our products. Please call me again (1-800-265-6681) if you require any additional information.

Yours truly,

require a drawing of the diode

See standard AVO-9B-C, Cat. No. 9,

\$5,429.00 US each, FOB destination.

Dr. Walter Chudobiak Chief Engineer

WC:pr Encl.

	RECEIVED DEC 1 7 1996
Lucent Technologies Bell Labs Innovations	600 Mountain Avenue Murray Hill, NJ 07974 USA
	FAX COVER SHEET
То:	Dr. Walter Chudo bia K
Company	Autech
Phone:	
FAX Phon	e: 1-800-561-1970
From:	Matthias Wattig
Room:	31-303
Voice Phor	ne: (908) 582 - 6200
FAX Phone	. (908) 582- 4702

Please find enclosed the drawing of the laser package (TO-3 package for SDL-5422-H1 laser divel). The 9.0. annels is MH 032676 If you have for the questions please let me lanow. Matthias Watting

Number of pages (including this page) 2



Jan 24/97

Disk: AVO-9 Marne: 9ABC.INS