



AVTECH ELECTROSYSTEMS LTD.  
NANOSECOND WAVEFORM ELECTRONICS

□ P.O. BOX 265  
OGDENSBURG, NY  
U.S.A. 13669-0265  
TEL: (315) 472-5270  
FAX: (613) 226-2802

☒ BOX 5120 STN. F  
OTTAWA, ONTARIO  
CANADA K2C 3H4  
TEL: (613) 226-5772  
FAX: (613) 226-2802

### INSTRUCTIONS

#### MODEL FOICA-AMP

- 1) Connect IN port of FOICA-AMP to OUT port of Model AVR-63-C.
- 2) Set one or both AMP controls on the AVR-63-C to near max CW.
- 3) Use the one turn AMP control on the FOICA-AMP to provide the desired amplitude to the high impedance load.
- 4) If the AMP controls on the AVR-63-C are set near max CW, then the spurious out will be less than 1% of the main pulse amplitude for all settings of the FOICA-AMP control knob.

11.19.92

added to AVR-G3-C, SN 6398

for FOIC