

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

SINCE 1975

TEL: 1-800-265-6681 FAX: 1-800-561-1970 U.S.A. & CANADA BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772 FAX: (613) 226-2802

INSTRUCTIONS


MODEL AVX-D-3-PS-CSMB DELAY GENERATOR

S.N.:

WARRANTY

warrants products of Avtech Electrosystems Ltd. its manufacture to be free from defects in material and workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace said defective item. This warranty does not apply to units dissembled, modified or which have been subjected to conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation or liability assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.

GENERAL TEST ARRANGEMENT



87

- 1) The equipment should be connected as shown in the attached.
- 2) The load resistance may be in the range of 50 Ohms to an open circuit.
- 3) The PRF should be less than 500 Hz (if delays of 1 ms are to be observed).
- 4) The delay for output A is fixed at 100 ns.
- 5) The delay for output B is variable as follows:

RANGE	1	100	ns	to	1	us
RANGE	2	1	us	to	10	us
RANGE	3	10	us	to	100	us
RANGE	4	100	us	to	1	ms

- 6) The unit can be converted from 110 to 220V 50-60 Hz operation by adjusting the voltage selector card in the rear panel fused voltage selector-cable connector assembly.
- 7) For additional assistance:

Tel: (613) 226-5772 Fax: (613) 226-2802

Mov. 26/93

yhne erger wegt oorde bie genene 661 oor oor oorleg. Telefer troop

- You Matter 1994 in Radia 20 August 20 Matter 20 Ma Matter 20 Matte 20 Matter 20 Ma
- (1) " → hR induced be use "entropy" is a delegant." not and by be observed;
 - na mai na persono no parama seri trainte no pro-

- B) This amplify the structure from 1.00 to 200 BO B special ion contractions the wolf of the Ster of Ster Card on The truct pairs to finack the light line of Ster Ster to the completion on control.
 - Las bergen and dense problem as a set of the

STREAD CALLS INTO A