

AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS SINCE 1975

P.O. BOX 265 OGDENSBURG, NY U.S.A. 13669-0265 TEL: (315) 472-5270 FAX: (613) 226-2802

TEL: 1-800-265-6681 FAX: 1-800-561-1970 U.S.A. & CANADA

e-mail: info@avtechpulse.com

BOX 5120 STN. F OTTAWA, ONTARIO CANADA K2C 3H4 TEL: (613) 226-5772 FAX: (613) 226-2802

INSTRUCTIONS

MODEL AV-149-BW1-5K-PIN-SP1-A-NC-PD3 TRANSIMPEDANCE AMPLIFIER

S.N.:

WARRANTY

Electrosystems Ltd. warrants products its manufacture to be free from defects in material workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace This warranty does not apply to units said defective item. or subjected to been dissembled, modified which have conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation or liability assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.





Fig. 1 BASIC TEST SET-UP (PULSE MODE)

GENERAL OPERATING INSTRUCTIONS

- 1) The basic operation of the amplifier was confirmed using the pulse mode test arrangement shown in Fig. 1.
- 2) The AV-149 amplifier requires a prime power of ± 15 VDC (20 mA max).
- 3) To test the AV-149 in a sweep frequency mode (DC to 30 MHz) the AV-1000-C and the sampling scope should be replaced by a network analyzer.
- 4) The PD3 detector diode is installed in the 3 PIN socket when the unit is shipped. Note that a nylon spacer washer is placed between the diode package and the AV-149 chassis. Other PIN detector diodes may be inserted into the socket. The pin connections are as shown in Fig. 2.
- 5) The DC offset on the output may be adjusted from 0 to ±1.0 Volts using the 10 turn trim pot which is accessible on the detector side of the chassis.
- 6) For additional information:

Tel: (613) 226-5772 Fax: (613) 226-2802



DIODE SOCKET PIN CONNECTIONS Fig. 2

- ANODE CASE
- 1) 2) 3) CATHODE

O.t. 7/96

Disk: AV-Marie: 49BW15KP. INS