



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS
SINCE 1975

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

TEL: 1-800-265-6681
FAX: 1-800-561-1970

e-mail: info@avtechpulse.com
<http://www.avtechpulse.com>

P.O. BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

SLR7A-N REPLACEMENT INSTRUCTIONS

- 1) **CAUTION !!** DC and Pulse potentials as high as 750 Volts exist in this chassis (when active) and so extreme caution must be employed when repairing the unit. Repairs should be completed by a worker who is skilled in high voltage technology and high quality soldering techniques.
- 2) Rotate the amplitude control fully counter clockwise and turn the prime power off. Let the instrument sit for 10 minutes to discharge all high voltages.
- 3) De-solder the two red and the two blue lines to the original SLR-7A-N module (A,B,C&D) and de-solder the high voltage line which connects to the orange 1 uFD capacitors (e)
- 4) De-solder the black RG174 output cable. Use low heat so as to not damage the cable.
- 5) Unscrew the two 4-40 Phillips screws and discard the original module.
- 6) Install the new module.