



AVTECH ELECTROSYSTEMS LTD.
NANOSECOND WAVEFORM ELECTRONICS

P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802

BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

INSTRUCTIONS

MODEL AVR-A-1-PW-CR1 PULSE GENERATOR


S.N.:

WARRANTY

Avtech Electrosystems Ltd. warrants products of its manufacture to be free from defects in material and workmanship under conditions of normal use. If, within one year after delivery to the original owner, and after prepaid return by the original owner, this Avtech product is found to be defective, Avtech shall at its option repair or replace said defective item. This warranty does not apply to units which have been disassembled, modified or subjected to conditions exceeding the applicable specifications or ratings. This warranty is the extent of the obligation or liability assumed by Avtech with respect to this product and no other warranty or guarantee is either expressed or implied.

A.

TEST ARRANGEMENT



GENERAL OPERATING INSTRUCTIONS

- 1) The equipment should be connected in the general fashion shown above. Since the AVR unit provides an output pulse rise time as low as 10 nsec a fast oscilloscope (at least 50 MHz and preferably 200 MHz) should be used to display the waveform. Also, if a load of other than 50 ohm is employed, the length of coaxial cable between the AVR unit and the load should not exceed about 5 feet or the output waveform may be degraded by the resulting reflections.
- 2) The magnitude of the output pulse is controlled by the front panel one turn pot (AMP). Maximum clockwise rotation of the pot provides the maximum output.
- 3) The output pulse width is controlled by the one turn PW pot.
- 4) In the event of severe overloading, the output switching elements (Avtech Part No. SL9H) may fail. The SL9H units are readily replaced by removing the four screws which affix the small cover plate to the bottom of the AVR chassis. The SL9H units may then be extracted from their sockets using needle nose pliers. When replacing the SL9H units take care to ensure that the short lead is placed adjacent to the black dot on the AVR chassis.

The first step would be to determine the number of copies of the document that are to be made. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection.

The second step would be to determine the number of copies of the document that are to be made. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection.

The third step would be to determine the number of copies of the document that are to be made. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection.

The fourth step would be to determine the number of copies of the document that are to be made. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection. This would be done by counting the number of copies of the document that are currently in the library's collection.