



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS
SINCE 1975

□ P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802


TEL: 1-800-265-6681
FAX: 1-800-561-1970
U.S.A. & CANADA

e-mail: info@avtechpulse.com

✕ BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

-R4 INSTALLATION INSTRUCTIONS

- 1) The R4 bracket is designed to attach to the chassis side panel using 4 6-32 screws.
- 2) It may be necessary to drill and tap the 4 holes on each side of the chassis. Before drilling, remove the top cover (by removing the 4 Phillips screws on the back panel and then sliding the cover back and off). Confirm that there are no components and wires in the area of drilling. If there are such obstructions, they must be moved.
- 3) For hole location purposes, the R4 bracket may be used as a template.



R4


0.70 cm

0.70 cm

2.10

2.50 cm

6-32 x 4



Four slots to
fit into slots
in the extension.



AVTECH ELECTROSYSTEMS LTD.

NANOSECOND WAVEFORM ELECTRONICS
SINCE 1975

□ P.O. BOX 265
OGDENSBURG, NY
U.S.A. 13669-0265
TEL: (315) 472-5270
FAX: (613) 226-2802


TEL: 1-800-265-6681
FAX: 1-800-561-1970
U.S.A. & CANADA

e-mail: info@avtechpulse.com

✕ BOX 5120 STN. F
OTTAWA, ONTARIO
CANADA K2C 3H4
TEL: (613) 226-5772
FAX: (613) 226-2802

-R RACK MOUNT KIT INSTALLATION INSTRUCTIONS

- 1) Remove the four 6-32 Phillips screws on each side of the instrument.
- 2) Place the rack mount angles over the holes and install the 6-32 screws as shown below.



May 7/97

Disk: AVX-S, -R

Name: -R4-INS